
ATTENTION PLEASE READ THIS FIRST!!

In order for your Dynamo 12V power supply to operate properly and efficiently, please follow the instructions below.

- Before initial use, fully charge your Dynamo upon delivery.
- After extended use, recharge your Dynamo as soon as possible.
- Be sure to recharge the Dynamo every 30 days, regardless of amount of use.
- DO NOT completely drain the power supply. If the “Needs Charging” light illuminates, stop use and recharge immediately.

Following these simple instructions will insure the maximum lifespan of your Dynamo 12V power supply. The Dynamo 90-day limited warranty does not apply if the instructions above are not followed.



Customer Support (800) 676-1343
E-mail: support@telescope.com

Corporate Offices (831) 763-7000
89 Hangar Way, Watsonville, CA 95076